

AUTO TIMER NA & TURBO

SAFETY WARNING Failure to obey this werning may cause server injury or damage.

Please read carefully, and pay attention to the following symbols:

⚠ WARNING

Failure to obey may result in death or serious injury.

- Be sure to shut off the engine when sleeping inside the vehicle, this may lead to exhaust poisoning.
- Do not leave the engine running in closed environments, this may lead to exhaust poisoning.
- Never leave the vehicle wile the engine is running, this could lead to accidents.
- Before installation, make sure the vehicle is stationary and engine turned off.
- This product should ONLY be installed by professional installers.
- Remove ignition key and disconnect negative battery terminal.
- Do not begin installation until the vehicle engine and any contact components are cool.
- This product should be installed in a place where they can not fall or move and damage the vehicle or affect driving.
- Please take care when installing this product so it does not interfere with any connections relating to safty equipments such as air bag, seat bealts, and safety devices.
- Never disassemble, modify, or tamper with the unit, this may result in electrical fire and void any factory limited warranty.
- Discontinue to use this product if there is a smoke or burning order, and return the product to the place of purchase.
- Never adjust this unit while driving, obey all traffic rules and regulations.

⚠ CAUTION

Indicates risks of personal injury or damage to product.

- Always connect the hand brake wire.
- This product is designed ONLY for DC12V vehicles. Do NOT use the product on 24V vehicles.
- Insulate any unused wires and reattach any lose connection that maybe caused from installation.
- Use only the wire harness provided, if additional wires are required, be sure to use the same gauge and quality wires.
- Be sure to mount this unit away from any area that may affect driving.
- Excessive force on the terminals may result in damage to product. Please hold on the connector securely when disconnecting.

CHECK & CONFIRM

This symbol indicates the need to confirm a particular tasks has been properly compeleted.

SPECIAL NOTES:

Remote Door Lockss or Adjustable Steering Columns may not function properly after installation of this unit. Be sure to test unit operation and parking brake safety wire after installation.

PARTS LISTS:













Control Unit x 1 Relay Unit x 1

Fastner x 2 Electro Tap x 1

Double Side Tape x 4


Instruction Manual x 1

WIRING DIAGRAM

- Disconnect the negative battery terminal before wiring.
- Locate the key switch harness, and refer to the wiring diagram (below) for hardwire.
- Connect the Timer harness connector to relay.
- Connecting the O2 sensor signal wire to *optional wideband controller and sensor (Innovate Motorsports P/N: 3769). - refer to Special Notes (below)
- Connecting the ground wire to wideband controller ground. refer to Special
- Connecting the parking brake switch refer to Special Notes (below).

Special Notes:

- AFR Display & Auto Mode only function when using *optional wideband controller and sensor (Innovate Motorsports P/N: 3769). Range 7.4 to 22.4 AFR, 0-5v linear.
- Vehicles NOT using the AFR Display, ground the (Black) wire to chassis.
- Parking Brake Switch with the IG Key ON, please be sure to check that the parking brake switch reads 12V when brake is down, and reads 0V when when brake is up.



CHECK & CONFIRM


Safety Switch Check (Parking Brake Safety Switch)

- Pull the parking brake up, start the engine, and make sure the IG key is ON.
- Set the timer to any desired setting above 20 seconds.
- Turn the IG Key OFF to activate the timer countdown.
- Release the parking brake down during the timer countdown.
- Be sure the engine shuts off completely.


OPERATION

AUTO TIMER







TO TURN OFF the Auto Timer



TURN ON the Auto Timer



CHANGING THE IDLING TIME DURING COUNTDOWN




AFR


This function requires an "optional Innovate Motorsports wideband controller and O2 sensor (PN: 3769). The voltage input configration is Ov at 7.4 AFR, and 5v at 22.39 AFR.




PART NAMES & FUNCTIONS




SETTING




SETTING (MINIMUM BATTERY VOLTAGE WARNING)



SETTING AFTER IDLING TIME (COUNTDOWN TIME)





www.tuneyourengine.com