






TX-3 RPM Switch Relay Wiring Instructions



PIN Out

-  **#87 NO Normally Open (RED) (To Device)**
-  **#85 Coil Ground - (WHITE) (From TX-3 Green/Red)**
-  **#86 Coil Positive + (YELLOW) (Switch Source)**
-  **#87a NC Normally Closed (BLUE) (Not Used)**
-  **#30 Battery / Engine GROUND (BLACK)**

